



DS & SL Maddick & Sons PTY LTD  
ACN 140 340 352  
PO Box 38  
Highfields QLD 4352  
Ph: 07 4696 7533  
Fax: 07 4696 7644  
[info@heritageconcretesleepers.com.au](mailto:info@heritageconcretesleepers.com.au)

## Installation of Heritage Concrete Sleeper Interlocking Posts One and Two Sleepers High

1. First place your posts where you are going to put your Garden Bed, allowing 1750 mm apart this is the length of the sleepers, (A little trick is to cut a straight piece of Aluminium Box or Straight piece of wood at the same length of a sleeper and use this to get your levels right and distances between Posts this will allow you to lift the sleeper in once and once only).
2. Mark on the ground where the posts are and remove them.
3. Dig a hole approx, 100mm Diameter, larger than the post and;
  - a. For **One High Interlocking Posts** approx;  
180mm deep for Joiners,  
150mm deep for 45 degree corners,  
220mm deep for Right Angle corners, and
  - b. For **Two High Interlocking Posts**;  
240mm deep for Joiners, and  
120mm deep for Corners.
4. Then place approx 10 to 20 mm, of Crusher Dust, Bedding Sand, or a like medium in the bottom of the hole.
5. Place Post in desired position and Raise or lower using Dust or Sand then place a Sleeper or Length of Aliminium into interlocking Post and with a Spirit Level ensure that it is all level. Then move on to the next post and continue until all posts are in place. Then place sleepers into posts and stand back and have a look making sure all is level and looks good to the eye.
6. Do not back fill any posts until you are satisfied all sleepers and posts are in the desired position and level,
7. Back fill and simply use the back end of your crow-bar or like item and go around and compact dirt and fill around posts.

8. Fill garden bed to desired level and plant what your desires are.
9. Once back filled and landscaped sit back and have a cold beer and enjoy a Heritage Concrete Retaining Wall that will never have to be replaced.

Congratulations on buying and installing a Heritage Concret Sleeper product. I hope we can be of assistance in the future.

Any Querries please don't hesitate to give us a ring

**Heritage Concrete Sleepers & Pre-Cast Concrete Slabs**  
**ABN 15 140 340 352**

**Mobile: 0409 134 221**

**Phone: 07 4696 7533**

**Fax: 07 4696 7644**

**Web Site: [www.heritageconcretesleepers.com.au](http://www.heritageconcretesleepers.com.au)**

**Enquires: [info@heritageconcretesleepers.com.au](mailto:info@heritageconcretesleepers.com.au)**